

CameraPak® Selection Guide

CAMERA AND LENS, NO MOUNT

Each CameraPak part number consists of a prefix (camera component) and suffix (lens component). To create the CameraPak of your choice, select the desired camera and lens components and combine the prefix and suffix part numbers.

Example: **C10DN-6** + **V50A** = **C10DN-6V50A** OR
C3701H-2 + **V50A** = **C3701H-2V50A**

Camera Number CameraPak Prefix Iris Type Lens Type Focal Length CameraPak Suffix

NTSC

CCC1390H-6	C1390H-6
C10DN-6	C10DN-6
CC3751H-2	C3751H-2
CC3701H-2	C3701H-2
C10CH-6	C10CH-6

PAL

CCC1390H-6X	C1390H-6X
C10DN-6X	C10DN-6X
C10DN-7X	C10DN-7X
CC3651H-2X	C3651H-2X
CC3701H-2X	C3701H-2X
C10CH-6X	C10CH-6X
C10CH-7X	C10CH-7X

A

+

Camera Number	CameraPak Prefix	Iris Type	Lens Type	Focal Length	CameraPak Suffix
Auto Iris	Varifocal Infrared (13VDIR Series)			2.8~11 mm	R11A
				3~8.5 mm	R3A
				7.5~50 mm	R75A
	Varifocal (13VD Series)			1~3 mm	V1A
				2.5~6 mm	V2A
				2.8~12 mm	V21A
				3~8 mm	V3A
				5~40 mm	V5A
				5~50 mm	V50A
				5.5~82.5 mm	V55A
	Fixed Focal Length (13FD Series)			2.3 mm	F2.3A
				2.8 mm	F2.8A
				4 mm	F4A
				8 mm	F8A
	Adjustable		Varifocal (13VA Series)		
		2.5~6 mm			V2
		2.8~12 mm			V21
		3~8 mm			V3
		5~40 mm			V5
		5~50 mm			V50
Fixed Focal Length (13FA Series)			5.5~82.5 mm		V55
			2.3 mm		F2.3
			2.8 mm		F2.8
			4 mm		F4
			8 mm		F8

B

=



C10DN-6V50A



C3701H-2V50A

C